Dec 2014

Resene Super Gloss

enamel

Resene Super Gloss is based on a tough solventborne resin for fast drying and durability in all hardwearing areas. This lower odour formulation is easy to apply and dries to a mirror gloss finish without the unwanted and strong solvent odours associated with traditional solventborne products.

exterior/interior

Typical uses

- Architraves
- Bathrooms
- Furniture
- Kitchens
- Laundries
- Plywood
- Skirtings Timber doors
- Wallboards
- Weatherboards
- Window frames

Physical properties

Vehicle type Alkyd

Pigmentation

Primer required

Undercoat required

Dry film thickness

Usual no. of coats

Heat resistance

Clean up

Abrasion resistance

Chemical resistance

Theoretical coverage

Titanium dioxide Solvent

Low odour hydrocarbon, less than 1% aromatic

hydrocarbon content

Finish Full gloss Colour

Selected Resene Total Colour System, including BS5252, Multi-Finish, Whites & Neutrals and The

Dry time (minimum) 4 hours at 18°C Recoat time (minimum)

16 hours

Yes

Yes

16 sq. metres per litre

28 microns at 16 sq. metres per litre

1-2

Very good

Acid - good; alkali - poor

Good

Solvent resistance Good Thinning

Resene Thinner No.2 (lower odour) or Mineral turps

(brush/roller); Resene Thinner No.9 (spray) Resene Thinner No.2, Mineral turps or Resene

Brush Cleaner (brush/roller); Resene Thinner No.9

VOC 427 grams per litre (see Resene VOC Summary)

Performance and limitations

Performance

- 1. Lower odour formulation, less than 1% aromatic hydrocarbon content.
- 2. May be applied over a wide range of temperatures.
- 3. Excellent adhesion to Resene Enamel Undercoat (see Data Sheet D44) and Resene Acrylic Undercoat (see Data Sheet D404).
- 4. Available in a wide range of colours.

Limitations

- Ensure the correct primer or sealer is used.
- Use the appropriate tinted undercoat when using tinted Resene Super Gloss. Resene Acrylic Undercoat (see Data Sheet D404) and Resene Enamel Undercoat (see Data Sheet D44) are available to facilitate perfect hiding and finish.
- 3. Due to waxes used in particle and fibreboard, it is essential that Resene Quick Dry (see Data Sheet D45) is used as the first coat on these substrates.
- 4. Drying can be affected by low temperatures and high humidity.
- May yellow in dark areas.

Please ensure the current Data Sheet and Safety Data Sheet are consulted prior to specification or application of Resene products. View Data Sheets online at www.resene.com/datasheets. If in doubt contact Resene.

Super Gloss enamel

Surface preparation

Clean down thoroughly to remove all dirt, dust and loose material. Ensure surface is free from oil, grease and mould. Any timber that has been exposed to weather for more than one week requires thorough sanding of the surface or treatment with Resene TimberLock (see Data Sheet D48).

If moss and mould are present, treat with Resene Moss & Mould Killer (see Data Sheet D80). Waterblasting at 21,000 kps (3000 psi) is the best surface preparation method prior to painting weathered cementitious surfaces or galvanised steel.

Prime as per following schedule:

Galvanised steel

Resene Galvo One (see Data Sheet D41).

Particle board

Resene Quick Dry (see Data Sheet D45).

Plasterboard

Plasterboard and stoppings in non wet areas should be primed (e.g. Resene Broadwall Waterborne Wallboard Sealer - see Data Sheet D403). Fibrous plaster or plasterboard and stoppings in wet areas should be sealed with Resene Sureseal (Data Sheet D42). Resene Sureseal (see Data Sheet D42) must be used where plasterboard has yellowed due to prolonged exposure to sunlight.

Timber - Matai, Spotted Gum and Totara

Resene Quick Dry (see Data Sheet D45).

Timber - exterior (all other timbers)

Resene Wood Primer (see Data Sheet D40) or Resene Quick Dry (see Data Sheet D45).

Timber - interior (all other timbers)

Resene Quick Dry (see Data Sheet D45) or Resene Enamel Undercoat (see Data Sheet D44).

Varnished surfaces, laminated surfaces

Resene Waterborne Smooth Surface Sealer (see Data Sheet D47a).

Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.

Application

Apply by brush, roller (Resene No.5 roller sleeve) or spray.

- New Prepare and prime as above. Apply one coat of Resene Acrylic Undercoat (see Data Sheet D404) or Resene Enamel Undercoat (see Data Sheet D44) in required colour. Allow to dry then sand lightly. Dust off. Apply one to two coats of Resene Super Gloss in required colour. Some bright colours may require an additional coat.
- Repaint Prepare surface and spot prime as above. Thoroughly sand any existing solventborne enamel
 paint finish to ensure adhesion of subsequent coats. Apply one coat of Resene Acrylic Undercoat (see Data
 Sheet D404) or Resene Enamel Undercoat (see Data Sheet D44) in required colour. Allow to dry then sand
 lightly. Dust off. Apply one to two coats of Resene Super Gloss in required colour. If applying over existing
 Resene Super Gloss, then use two coats of Resene Super Gloss in required colour directly over the existing
 paint finish. Some bright colours may require an additional coat.

Precautions

- 1. While this product is formulated using low odour solvents, you must ensure there is good ventilation during application and curing. Avoid breathing vapour.
- 2. Ensure correct primer and/or sealer is used.
- 3. Fill all nail holes and cracked timber after priming.
- 4. FLAMMABLE Keep away from heat and open flame. Keep closed when not in use.



Super Gloss SDS

Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. View Data Sheets online at www.resene.com/datasheets. If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.