

# creating a wood-effect paint finish



You'll need: p220 grit sandpaper; Resene Hot Weather Additive; Resene Lustacryl waterborne paint; paint brushes (size to correspond with job at hand); rubber grain-effect combs, clean rags and water.

## Step 1 >

Prepare all surface areas by washing, sanding and, where necessary, filling any holes or imperfections, then apply Resene Quick Dry acrylic primer undercoat and allow to dry.




## Step 2 >

Use a fine grade sandpaper – p220 is best – to smooth off the finish. Dust clean.

## Step 3 >>

Next comes the first topcoat. Apply using a crow's foot technique to achieve a criss-cross finish. Smaller surfaces need only be painted in one direction.



For more paint effects ideas visit [www.resene.co.nz/homeown/paint\\_effects/paint\\_effects.htm](http://www.resene.co.nz/homeown/paint_effects/paint_effects.htm).



## << Step 4

Add Resene Hot Weather Additive into your second topcoat colour to increase drying time and allow more ease of manipulation with the comb. Employ the same crow's foot – criss-cross – brushstrokes to ensure a smooth, even finish.

## < Step 5

After painting, with a steady hand, draw the comb across the surface to create your desired effect.

## Step 6 >

The added Resene Hot Weather Additive should ensure you have a reasonable amount of working time to create grain effects. Leave to dry for at least 24 hours.



## Step 7 >

When completely dry, seal the combed surfaces with a coat of Resene Aquaclear satin. This will provide a durable wearing surface and soften the appearance of combed areas, creating a more natural effect.

To achieve this cedar look, we used Resene Aubergine and Resene Hairy Heath. Any combination of colours can be employed.

