



Create this handy laundry box from a cardboard 'Disbin' and a selection of clean green Resene colours.

★☆☆ Difficulty level ★ easy ★★ moderate ★★★ challenging

Weekend DIY with Mark Rayner – 3

You will need:

- Cardboard Disbin (available from www.disbin.com)
- Masking tape
- Paintbrushes
- Pencil
- Resene Lumbersider tinted to Resene Bathurst and Resene Poprock
- Resene SpaceCote Low Sheen Kitchen & Bathroom tinted to Resene First Light
- Resene Quick Dry
- Tape measure



Step one

Assemble the Disbin base and lid following the manufacturer's instructions.



Step two

Apply one coat of Resene Quick Dry to the Disbin base and lid, allowing two hours to dry.



Step three

Apply two coats of Resene Poprock to the base of the Disbin, allowing two hours for each coat to dry.



Step four

Apply two coats of Resene Bathurst to the lid of the Disbin, allowing two hours for each coat to dry.



Step five

Mask off six 100mm strips around the base of the Disbin, as shown.



Step six

Paint alternate strips with one coat of Resene Bathurst, allowing two hours to dry.



Step seven

Apply a second coat of Resene Bathurst and carefully remove the masking tape before the paint dries. Allow two hours to dry.




Step eight

Complete the look with your laundry. Paint walls and skirting with two coats of Resene SpaceCote Low Sheen Kitchen & Bathroom tinted to Resene First Light, allowing two hours for each coat to dry.



Top tip:

Use purple low-tack masking tape to avoid any potential damage to paintwork.



Other ideas:

Create a funky toy storage box by painting a Disbin with two contrasting colours from the Resene KidzColour range.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.co.nz or www.resene.com.au.

Check out our special Artists section online www.resene.co.nz/artists/artists_canvas.htm or www.resene.com.au/artists/artists_canvas.htm.